

Jan 2, 2020

This document describes new features and enhancements introduced in MecSoft's VisualCAD/CAM product. NOTE: This information is provided in good faith but MecSoft reserves the right to modify or omit any of the items described in this document when the product is released.

Contents	
VisualCAD 2020	
VisualCAM 2020	7
G-Code editor Module	
Modes of Operation	
Profile-Nest Module	
Mill-Turn Module	
Common CAM EnhancementS	
Licensing Enhancements	
What's new in VisualMILL 2020	
Usability Enhancements	
2-Axis Enhancements	
3-Axis Enhancements	
4 Axis Toolpath Enhancements	
5 Axis Toolpath Enhancements	
Drilling Enhancements	
Tooling Enhancements	
Feeds/Speeds Enhancements	

Simulation Enhancements
Machine Tool Simulation Enhancements
Knowledge Base Enhancements
Post Processor Enhancements
Bugs Fixed
What's new in VisualTURN 2020
What's new in VisualNEST 2020
What's new in VisualART 2020

This document describes the new functionality that is being introduced with the release of the VisualCAD/CAM 2020 product. This document is organized by listing and describing each of the enhancements incorporated into each of the constituent modules of VisualCAM.

VISUALCAD 2020

The following enhancements have been made to VisualCAD 2020

1. Bitmap background object to assist in modeling has been implemented. This allows for users to sketch outlines of bitmaps. A screen shot of a placed bitmap and the various functions available is shown below.



BACKGROUND BITMAP FUNCTIONS

- 1. Place Allows placement of the bitmap into a viewport
- 2. Move Allows translation of the placed bitmap
- 3. Scale Allows the scaling of the placed bitmap
- 4. Hide/Show User can toggle the visibility of the placed bitmap
- 5. Grayscale Allows conversion of the color bitmap to a grayscale one
- 6. Transparency User can change the transparency for better drawing control using a slider control
- 7. Remove Removes the placed bitmap

2. Zero radius fillet option has been introduced. A zero-radius fillet is essentially an extension of the two curves to their common intersection point. A simple example is shown below. Here two lines can be extended and intersected. Using the fillet command and specifying zero radius for the fillet accomplishes this.



- 3. An option to offset curves using sharp corners in addition to the existing rounded corner has been introduced.
- 4. 3 Point Angle, 3 Point Circle and 3 Point Arc dimension commands were enhanced to use point input.
- 5. An option to specify a snap distance for curve selection and object snaps was introduced.

Object Snap Settings			
Snap Radius:	15	▲ ▼	pixels
	_	-	

The snap radius in pixels can now be defined in the CAM preference dialog to improve snap selections. A portion of the CAM System preferences dialog is shown to the left.

1

- 6. Dynamic display of movements in all Analysis commands has been implemented
- 7. The display of edge radius/diameter by edge selection instead of having to extract a curve for arc analysis was implemented
- 8. Dxf/Dwg translators have been updated using the latest OpenDWG libraries. The new libraries fix some important bugs in the translation of Dxf/Dwg files. In addition to this, solids import from DWG files has been implemented in 2020.
- 9. IGES/STEP/Parasolid/SAT translators have been updated with new libraries. This is a maintenance release with multiple bugs fixed in the translators.
- 10. Vertical scroll bar in the Options dialog was introduced for people working with older monitor screens

VISUALCAM 2020

VisualCAM 2020 is a plug-in that runs inside the VisualCAD 2020 CAD product and hosts the following modules:

- 1. MILL
- 2. TURN
- 3. NEST
- 4. ART
- 5. GCODE EDITOR (new in 2020)
- 6. PROFILE-NEST (new in 2020)
- 7. MILL-TURN (new in 2020)

Each of these modules can be licensed and invoked separately of the other modules. This section describes the various enhancements and improvement to each of the modules.

Licensing Information for the new modules

- 1. Annual Maintenance SUBSCRIPTION (AMS) Customers of VisualCAD/CAM PRO & PRE Configurations will get a license of all three new (MILL-TURN, GCODE-EDITOR and PROFILE-NEST) modules free of cost
- 2. Annual Maintenance SUBSCRIPTION (AMS) Customers of VisualCAD/CAM STD & EXP Configurations will get a license of both the GCODE-EDITOR and PROFILE-NEST modules free of cost

G-CODE EDITOR MODULE

A new G-code editor module has been introduced in the 2020 product. A screen capture of this module with G-code being displayed is shown below.



This module allows various functions to be performed on the G-code files. These are described below.

MODES OF OPERATION

There are two modes of operation of the G-Code editor module. These are as follows:

- Project Mode This mode is active when commands to work with the various objects such as stock, tools as well as the loaded G-code files are needed. In this mode the main tree control will be displayed in the browser window.
- Editor Mode This mode is active when commands to work with a single G-code file are necessary. This mode is launched by selecting a single G-code file in the main tree-control and then editing it by either double clicking this icon or by clicking the right mouse button and selecting the edit command. In this mode the actual G-code lines will be displayed in the browser window.

SETUP MODE



PROJECT TAB FUNCTIONS

- 1. Stock allows the definition of the stock model for simulation:
 - Box stock, Part Box Stock, Cylinder Stock, Part Cylinder Stock
- Tool Library– allows the loading of a tool library created in the CAM system
- 3. Tool Numbers allows the definition of the tool crib to be used in simulation
- 4. Load Allows loading of G-code file
- 5. Info Overall information of selected or all loaded G-code files
- 6. Merge Allows merging of selected G-code files into one
- 7. Transform allows move, translate, rotate and mirror of G-code files
- 8. XY Instance allows the 2 D instancing of selected G-code files
- 9. Z Instance allows the Z instancing of selected G-code files
- 10. Save Save all modified G-code files
- 11. Output Output G-code files to an external program

EDIT MODE

In the edit mode, 3 tabs are available to the user. These are

- Edit Tab Functions for text navigation and simple text editing
- G-code Edit Tab Functions for editing the actual code
- Simulate Tab Functions for simulation/back-plotting

EDIT TAB



EDIT TAB FUNCTIONS

- 1. Cut Cut the text selection
- 2. Copy Copy the selected text to the clipboard
- 3. Paste Paste the clipboard text back to the editor
- 4. Undo Undo the previous edit operation
- 5. Print Print the edited G-code file
- 6. Save Save the edited G-code data to a file
- 7. To Bottom Navigate to the bottom of the edit control
- 8. To Top Navigate to the top of the edit control
- 9. To next tool change Navigate to the next tool change statement
- 10. To next spindle- Navigate to the next spindle statement

G-CODE EDIT TAB

VisualCAM - G-Code Editor Edit G-Code Edit Simulate Add Line #s AV Insert Spaces AV Upper Case Info Del Line #s AV Del Spaces Lower Case

G-CODE EDIT TAB FUNCTIONS

- 1. Add Line #s –Inserts line numbers to the G-code lines
- 2. Delete Line #s Removes all line numbers from the G-code lines
- 3. Insert Spaces This inserts spaces between G-code blocks in the file
- 4. Delete Spaces This deletes any spaces between G-code blocks
- 5. Upper Case This makes all text upper case in the file
- 6. Lower Case This makes all text lower case
- 7. Info This provides the statistics on the G-code file

SIMULATE TAB



SIMULATE TAB FUNCTIONS

- 1. Play Continuously loop through the simulation
- 2. Step by count The count can be changed by using the slider bar or by setting the count in the options dialog
- 3. Step by levels Step the simulation in levels if levels are detected in the toolpath
- 4. Simulate to End Simulate the toolpath to the end
- 5. Pause the simulation
- 6. Stop Stop the simulation

PROFILE-NEST MODULE

A new Profile-NEST module has been introduced in the 2020 product. This module allows nesting of 2 ½ Axis Profile toolpaths instead of just curves as the NEST module currently does. This module is tailored for the woodworking and flat panel machining industries. A screen capture of the UI is shown below.

💓 🗅 🖆 🖬 🤀 = 🐇 🖺 🗠 = 🍋 = 🤃 🔘 =		Profile-NESTQuickStartGuide_Completed.vcp - MecSoft VisualCAD 2020	- 🗆 ×
Home Display Modeling Aids Curve Modeling Surface Modeling Solid M	eling Mesh Modeling Dimensions A	Analyze	⊗ Style ~ 🚱
			0
Command			
VisualCAM - Machining Browser	Iso View 1	은 안 한 🛛 🖉 🖓 📑 🏠 🏠 🔄 🖉 🦧	
Profile-NEST Ja Nest Simulate			
Machine G Stock * G Work Zero Maching Report Report Alian T 21/2 Avis Profiling			
Sheets 🗄 Material 📴 Nesting Parameters			
Machine Setup Stock Operations To Nest		$\langle b \rangle \langle b \rangle$	
🗉 🌈 Machining Job			
Post - Laguna_BR_IQ			
Gorations to Nest			
2 1/2 Axis Profiling (Part 1)			
arr 2 1/2 Axis Profiling (Part 2) arr 2 1/2 Axis Profiling (Part 3)			
🗉 🦕 🎦 2 1/2 Axis Profiling (Part 4)			
Nested Sheets		$area tan area tan \nabla$	
Birrie Sheet 2			
B			
	_ Coth		
😼 🚓 🖉 🖉 🖉			
VisualCAM - Machining Objects		arth ton arth ton arth ton	
Tools			
⊟ J] Tools		Coloren 100 A Coloren 100 A Coloren 1	
FlatMilt 0.25			
A. 1996			
No Sort 💌 🖞 🦓			
HatMill: 0.25 #2 Dia:0.250, CRad:0.000, Taper:0.0 deg RPM: 24446 F: 14.7	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	18 International	
WORLD 13.932984 48.6/1206 0.000000 Units: INCH 🖾 🗔 🗸 🗸 🔏 🖉 😡	🔺 🦓 📑 🍸 💙 Default 🔹	(P)	

The Profile-NEST module launches a new browser window which has the following two tabs:

- Nest This tab is used to setup the sheets, the 2 ½ Axis Profiling operation to be nested, along with the various with other objects used in this module
- Simulate This tab is used to run the toolpath simulation and verify the nesting results



NEST TAB FUNCTIONS

- 1. Machine Defines machine tool (Same as MILL)
- 2. Post Defines Post (Same as MILL)
- 3. Sheets Define sheets to nest toolpaths in
- 4. Stock Create stock model (Same as MILL)
- 5. Align Align stock to toolpaths
- 6. Material Select material for stock (Same as MILL)
- 7. Work Zero Set work zero for operations (Same as MILL)
- 8. 2 ½ Axis Profiling Create operations with count information
- 9. Nesting Parameters Define parameters to nest
- 10. Nesting Report– Create nesting report



SIMULATE TAB FUNCTIONS

The simulation tab functions are the same as those found in the MILL module.



PROFILE NESTING WORKFLOW

- User creates one or more 2 ½ Axis Profiling operations. These can be considered as parent operations. User specifies the count of each of these operations to be nested.
- 2. The user defines additional nesting parameters including sheets to use for nesting.
- 3. The system will compute the nested operations and display them in the browser window under the Nested Sheets icon as shown here.
- Selecting and expanding each of the Sheet icons under the Nested Sheets icon will display all of the nested operations under this icon, as well as display them in the graphics window
- **5.** Once the nested operations are created, they can be postprocessed by selecting the Nested Sheets icon or each of the Sheet icons individually.

MILL-TURN MODULE

A new Mill-TURN module has been introduced in the 2020 version. This module allows programming of turning machines with a C-axis milling head. A screen shot of this module is shown below.





TURN TAB FUNCTIONS

The Turn tab is used to program turning operations on the part. Turning operations are created under a separate Setup icon in the Job tree of the Machining Operations browser.



MILL TAB FUNCTIONS

The Mill tab is used to program milling operations using the C-Axis head on the part. Milling operations are created under a separate Setup icon in the Job tree of the Machining Operations browser.



SIMULATE TAB FUNCTIONS

The Simulate tab is used to simulate the created operations, including both the Turn and Mill operations present in the file.

Screen shots of Tuning and Milling operations performed in the same part using the MILL-TURN module is shown below:



Turn roughing operation

isualCAM ۵ 🖉 - 🌾 ۵ MILL-TURN 10 Turn Mill Simulate
 Stock ▼
 Work Zero
 Other ▼

 Post
 Align
 Image: Part ▼
 Image: Part ▼
 Image: Part ▼
 Knowledge Base ▼

 Image: Part ▼
 Image: Part ▼
 Image: Part ▼
 Image: Part ▼
 Holes ▼
Turning ining Job Machine - Lathe Part - Defined Stock - Cylinder etup 1 (Turn Work Zero Turn Re Turn Finis etup 2 (Mill Work Zero 2 1/2 Axis F 🗟 🗦 🛷 🦑 🛵

Mill Facing operation on the same part

COMMON CAM ENHANCEMENTS

This section describes the common enhancements and changes to VisualCAM 2020.

- 1. A new version of the windowing system for VisualCAM has been integrated into the 2020 product. Additional window styles have been added to the CAM product as a consequence.
- 2. New simulation libraries from Machineworks Inc. has been incorporated into all the machining modules. These libraries have improved multithreaded performance significantly as well as fixed many reported issues.

LICENSING ENHANCEMENTS

The following enhancements have been implemented in the licensing system for VisualCAD/CAM.

- 1. Cloud hosted concurrent network licenses using network authentication service has been implemented. This is a simpler scheme for implementing multiple licenses on school and other organizational networks. This scheme will work only when client machines have constant internet access.
- 2. The license administrator can now push license settings to the HKLM registry to be used by network users without having to enter them at each client machine.
- 3. Password fields are now protected and not displayed in the case of settings being pulled from the HKLM registry. This is important to large enterprises and educational institutions.
- 4. Maintenance expiry date is now being displayed in the license status dialog. Also a prompt when maintenance is close to expiry will be shown at the start of the product.

WHAT'S NEW IN VISUALMILL 2020

This section describes the enhancements and changes to the MILL module.

USABILITY ENHANCEMENTS

1. Fixtures can now be defined in the MILL module. Collision detection of generated toolpaths with fixture geometry has also been implemented. Global fixture geometry can be selected and are displayed on the Machining Operations tree in the browser dialog.



Screen shot of the user of fixtures and their representation in the Machining Job tree in the browser window is shown above



FIXTURES IN SETUPS

Once defined, the fixtures can then be added to any Setup to enable their use in the Setup's machining operations.

2. Preferences dialog has been reorganized based on object and function specific dialogs to stream-line preferences.



3. Better display support for high resolution (4K) has been implemented with newer scalable function icons in various toolbars and ribbon bars.

2-AXIS ENHANCEMENTS

1. A true trochoidal cutting path has been introduced.



TRUE TROCHOIDAL MACHINING

This option can be used to cut slots as well as other confined areas in hard material. The user selects an open or closed curve and specifies a trochoidal width to machine.

2. Programming with rigid knives can now be done. This option has been added to the existing knife cutting operations. The knife will be retracted and rotated into the new orientation when this option is checked.



3. Cut side in profiling can be set based on nesting of profiles. The system uses the user defined settings for the outer most profile and then alternates the cutting sides for any inner profiles, regardless of the direction of the profile curves.





Profile toolpath with cut side on the left side of the curve

Profile toolpath with cut-side alternating based on profile nesting

- 4. Profile machining start points have been enhanced in the case of toolpaths with corner extension.
- 5. The user now has an option to fit arcs to 2 ½ Axis Engraving toolpaths

Cut Parameters	Entry/Exit	Advanced Cut Parame	ters Sorting	
Cut Arc Fi	tting rm Arc Fitting olerance (t)	0.0001	tt	

ARC FITTING IN ENGRAVING

This option can be used fit arcs in the 2 ½ Axis engraving toolpaths.

6. Taper tools can now be defined as reference tools in 2 ½ Axis re-machining operations.



TAPER TOOL IN RE-MACHINING

The taper angle can be set to create a taper or conical reference tool to create a 2 $\frac{1}{2}$ axis re-machining toolpath

7. Ramp height for ramping cut entries is set automatically now based on depth of cut in 2 ½ Axis machining modules. The tool now ramps from the previous cut level if the user sets a ramp height smaller than the height from the previous level to the current level.

3-AXIS ENHANCEMENTS

 Step Minimization Roughing (SMR) option has been introduced in Horizontal Roughing. The Horizontal Roughing operations can leave a large stairsteps that need to be cleaned up by an additional operation – typically a re-roughing operation. A more efficient method will be to rough the part using the largest step-down the tooling, material and other cutting conditions will allow and then cut the stair-step left by this step *after* the lower cut level has been machined.

Horizontal Roughing			×	
Cut Parameters Cut Levels	Engage/Retract	Advanced Cut Parameters		
Stepdown Control (dZ)	100 • 0.125 • 5 •			
Minimize Stair Steps? Intermediate Stepdown % (idZ) 25 ▼				

The advantages of this type of machining method are as follows:

- a. Decreased time for machining
- b. Lesser number of cutting tools used

STEP MINIMIZATION ROUGHING

Specifying intermediate steps will create Z levels between the original cut levels that will remove the stairsteps left by these cut levels.





Part machined without Step Minimization Roughing. Here the maximum depth of cut allowed for tool has been applied.

Step Minimization Roughing applied with intermediate steps. This allows the significant reduction of stair steps.

2. Ramp height for ramping cut entries is set automatically now based on depth of cut in Horizontal Roughing and Horizontal Re-roughing modules. The tool now ramps from the previous cut level if the user sets a ramp height smaller than the distance to the previous level.

4 AXIS TOOLPATH ENHANCEMENTS

1. 4 Axis non-projection toolpath algorithms have been re-written and made more robust to handle more complex cases.

5 AXIS TOOLPATH ENHANCEMENTS

1. New Moduleworks toolpath generation libraries for 5 axis machining have been integrated with the product.

DRILLING ENHANCEMENTS

1. Skim clearance for drilling operations was implemented.





Version 2019 behavior when Skim Clearance is set in drilling methods.

Version 2020 behavior when Skim Clearance is set in drilling methods.

TOOLING ENHANCEMENTS

1. Taper tool holders can now be defined for all mill and drill tools. These taper tool holders will participate in collision detection and other functions involving the tool holder.



All tool creation/edit dialogs have been updated to include taper holder definition.

Preview of a flat tool with a taper holder.

2. A new format tool library using CSV files has been implemented. CSV files now are segmented based on tool types.

FEEDS/SPEEDS ENHANCEMENTS

1. Feeds & Speeds information stared with the tool are now written out to the CSV format tool libraries.

SIMULATION ENHANCEMENTS

- 1. New simulation libraries were incorporated that fixes several issues as well as introduce performance improvements was implemented.
- 2. Collision detection between tool and fixture geometry was implemented. Detected collisions are displayed in red in the stock model.



3. Collision detection between tapered tool holders and geometry was implemented. Detected collisions are displayed in red in the stock model.



MACHINE TOOL SIMULATION ENHANCEMENTS

1. Additional machine tool models have been added as part of the installed machine tool simulation library.

KNOWLEDGE BASE ENHANCEMENTS

 Selection rules for defining work zero automatically in Knowledge Bases has been implemented. This allows for parametric definition of Work Zeros when a Knowledge Base is loaded. As an example, the user can specify the Work Zero to be at the South-East corner of the stock model and save a Knowledge Base. When this Knowledge Base is loaded, the work zero will be automatically set to the South -East corner of the current stock model. Previously the work zero would be set to the saved coordinates.

POST PROCESSOR ENHANCEMENTS

1. Ability to modify the APT CLS file using a separate program, during output was implemented

- 2. Rapid motion in all indexed operations are converted to use federate motions when setup is not aligned with the machine Z. This is done only when a head is defined and output to Local Coordinate system is NOT set.
- 3. Drill cycles need to be converted to simulated cycles if the setup is not aligned with the machine Z. This is done only when the machine has a head defined and output to Local Coordinate System Is NOT set.
- 4. New variables for MaxZ and MinZ output in the post have been added
- 5. If stock is not defined, UNDEFINED is output for the STOCK_X, STOCK_Y & STOCK_Z and other stock related variables
- 6. The issue with the Post-Processor Generator dialog dominating the display has been fixed.

BUGS FIXED

Numerous bugs have been fixed to make the product more reliable and robust.

WHAT'S NEW IN VISUALTURN 2020

A new MILL-TURN module has been introduced. In addition to this, multiple customer reported bugs were fixed in the TURN module.

WHAT'S NEW IN VISUALNEST 2020

A new PROFILE-NESTING module was introduced. In addition to this the following functions were introduced in the existing NEST module.

1. Moving every sheet's lower corner to the origin point on export was implemented.

In addition to this, multiple customer reported bugs were fixed in the NEST module.

WHAT'S NEW IN VISUALART 2020

No major enhancements were introduced in the ART module. Selected user reported bug-fixes were implemented.

WHAT'S NEW IN VISUALMESH 2020

New Machinework's Polygonica libraries were integrated to implement additional robustness and improved performance within most mesh functions.